

With the launch of KEPServerEX version 6, in November 2016, Kepware changed the part numbers for all of OPC software products

Below is a list of the previous version 5 parts numbers, versus the new version 6 part numbers

Please use the new v6 part numbers for all future purchases - of either v5 or v6 software.

- all software licenses issued are 'dual-purpose' and so can be use with v5 or v6 software

Please note :- After March 1st 2017, we will no longer be able to process orders bearing the previous part numbers



kepware®

KepServerEX V6
- Popular Driver Licenses

	<u>Previous</u>	<u>Current</u>	<u>Current</u>
	<u>KEPServerEX v5</u>	<u>KEPServerEX v6</u> <u>(or v5)</u>	<u>KEPServerEX v6</u> <u>(or v5)</u>
<u>Product Part Number</u>	<u>Product Part Number</u>	<u>Product Part Number</u>	<u>Support + Maintenance</u> <u>(Mandatory for 1st yr)</u>
<u>Manufacturing Suite</u>	<u>EX5-MNFNG-SUIT</u>	KWP-MNFNG0-PRD	KWM-MNFNG0-ATT
<u>Building Automation Suite</u>	<u>EX5-BLDAT-SUIT</u>	KWP-BLDAT0-PRD	KWM-BLDAT0-ATT
<u>IT & Infrastructure Suite</u>	<u>EX5-ITINF-SUIT</u>	KWP-ITINF0-PRD	KWM-ITINF0-ATT
<u>Oil & Gas Suite</u>	<u>EX5-OILGS-SUIT</u>	KWP-OILGS0-PRD	KWM-OILGS0-ATT
<u>Power Suite</u>	<u>EX5-POWER-SUIT</u>	KWP-POWER0-PRD	KWM-POWER0-ATT
<u>Simulation Suite</u>			
Advanced Simulator Driver			
Memory Based Driver	<u>EX5-ADVSM-NA00</u>	KWP-ADVSM0-PRD	KWM-ADVSM0-ATT
<u>DNP3 Suite</u>			
DNP3 Master Ethernet / Serial 1 to 10 Devices	<u>EX5-DNP30-NA01</u>	KWP-DNP301-PRD	KWM-DNP301-ATT
DNP3 Master Ethernet / Serial 11+ Devices	<u>EX5-DNP30-NA00</u>	KWP-DNP300-PRD	KWM-DNP300-ATT
<u>GE Suite</u>			
GE CCM, SNP & SNPX			
GE Ethernet & Ethernet Global Data (EGD)	<u>EX5-GEFNC-NA00</u>	KWP-GEFNC0-PRD	KWM-GEFNC0-ATT
<u>Mitsubishi Suite</u>			
Mitsubishi Serial & Ethernet			
Mitsubishi FX & FX Net			
Mitsubishi CNC Ethernet	<u>EX5-MITSU-NA00</u>	KWP-MITSU0-PRD	KWM-MITSU0-ATT
<u>Modbus Suite</u>			
Modbus Serial RTU, RTU unsolicited & ASCII			
Modbus Ethernet & Ethernet unsolicited			
Modbus Plus	<u>EX5-MDBUS-NA00</u>	KWP-MDBUS0-PRD	KWM-MDBUS0-ATT
<u>Omron Suite</u>			
Omron FINS Serial & Ethernet			
Omron Host Link			
Omron Process Suite & Toolbus	<u>EX5-OMRNF-NA00</u>	KWP-OMRNF0-PRD	KWM-OMRNF0-ATT
<u>Rockwell Suite</u>			
Allen-Bradley ControlLogix			
Allen-Bradley DH+			
Allen-Bradley DF1			
Allen-Bradley Ethernet & Ethernet unsolicited	<u>EX5-ABSTE-NA00</u>	KWP-ABSTE0-PRD	KWM-ABSTE0-ATT
<u>Siemens Suite</u>			
Siemens S5 AS511 & 3964R			
Siemens S7 200			
Siemens S7 MPI			
Siemens TCP/IP Ethernet & Ethernet unsolicited	<u>EX5-SIEMS-NA00</u>	KWP-SIEMS0-PRD	KWM-SIEMS0-ATT
<u>Siematic 505 Suite</u>			
Siematic 505 Serial & Ethernet	<u>EX5-SM505-NA00</u>	KWP-SM5050-PRD	KWM-SM5050-ATT
<u>KepServerEX V6 - Plug-ins</u>			
<u>Plug-ins (general)</u>			
Advanced Tag Plug-in	<u>EX5-ADTGO-NA00</u>	KWP-ADTGO0-PRD	KWM-ADTGO0-ATT
OPC Alarms & Events Plug-in	<u>EX5-ALMEV-NA00</u>	KWP-ALMEV0-PRD	KWM-ALMEV0-ATT
EFM Suite with EFM Exporter (1-49)	<u>EX5-EFMEX-NA00</u>	KWP-EFMEX1-PRD	KWM-EFMEX1-ATT
ODBC DataLogger Plug-in	<u>EX5-DLOGR-NA00</u>	KWP-DLOGR0-PRD	KWM-DLOGR0-ATT
Scheduler Plug-in	<u>EX5-SCDLR-NA00</u>	KWP-SCDLR0-PRD	KWM-SCDLR0-ATT
SNMP Agent Plug-in	<u>EX5-AGENT-NA00</u>	KWP-AGENT0-PRD	KWM-AGENT0-ATT
<u>Local Historian Plug-in</u>			
Local Historian Plug-In (1-500 Tags)	<u>EX5-LHIST-NA05</u>	KWP-LHIST1-PRD	KWM-LHIST1-ATT
Local Historian Plug-In (501 - 10,000 Tags)	<u>EX5-LHIST-NA10</u>	KWP-LHIST2-PRD	KWM-LHIST2-ATT
<u>IoT (Internet of Things) Plug-in</u>			
IoT Gateway Plug-In (MQTT, REST, ThingWorx) (up to 500 Tags)	<u>EX5-IOTGW-NA01</u>	KWP-IOTGW1-PRD	KWM-IOTGW1-ATT
<u>Splunk Plug-in</u>			
Industrial Data Forwarder Plug-In for Splunk (up to 500 Tags)	<u>EX5-SPLNK-NA01</u>	KWP-SPLNK1-PRD	KWM-SPLNK1-ATT

Unit 6 &, Kingfisher Business Park,
Arthur St
Redditch
Worcs. B98 9NW

www.mac-solutions.net

Official UK Preferred Distributor for Kepware

	<i>Previous KEPServerEX v5</i>	Current KEPServerEX v6	Current KEPServerEX v6
	<i>Product Part Number</i>	Product Part Number	Support + Maintenance (Mandatory for 1st yr)
<u>KepServerEX V6</u>			
<u>- Utility Drivers & Special Drivers</u>			
<u>DDE Server OPC-enabling Driver</u>			
DDE Client Driver	EX5-DDECC-NA00	KWP-DDECC0-PRD	KWM-DDECC0-ATT
<u>SNMP (Network Monitor)</u>			
SNMP Suite (including Ping)	1-15 Devices EX5-ISNMP-BA15	KWP-ISNMP1-PRD	KWM-ISNMP1-ATT
SNMP Suite (including Ping)	16-50 Devices EX5-ISNMP-EX50	KWP-ISNMP2-PRD	KWM-ISNMP2-ATT
SNMP Suite (including Ping)	Unlimited EX5-ISNMP-EN00	KWP-ISNMP0-PRD	KWM-ISNMP0-ATT
SNMP Agent	EX5-AGENT-NA00	KWP-AGENT0-PRD	KWM-AGENT0-ATT
<u>System Monitor Driver</u>			
System Monitor	EX5-SYSMN-NA00	KWP-SYSMN0-PRD	KWM-SYSMN0-ATT
<u>Custom Protocol Drivers</u>			
UCON User-Configurable Device Driver	EX5-UCOND-NA00	KWP-UCOND0-PRD	KWM-UCOND0-ATT
Custom Interface Driver	EX5-CUSID-NA00	KWP-CUSID0-PRD	KWM-CUSID0-ATT
<u>Wonderware InTouch OPC-enabling Driver</u>			
InTouch Client Driver	EX5-WWINT-NA00	KWP-WWINT0-PRD	KWM-WWINT0-ATT
<u>ODBC Database Client Driver</u>			
ODBC Client Driver	EX5-ODBCI-NA00	KWP-ODBCI0-PRD	KWM-ODBCI0-ATT
<u>OPC Connectivity, Tunnelling & Aggregation Driver</u>			
OPC DA, XML & UA Client Drivers	EX5-OPCCS-NA00	KWP-OPCCS0-PRD	KWM-OPCCS0-ATT
<u>KepServerEX V6 - Special Network Driver Licenses</u>			
<u>BACnet</u>			
BACnet	EX5-BCNET-NA00	KWP-BCNET0-PRD	KWM-BCNET0-ATT
<u>DeviceNet or Profibus (Hilscher Universal - needs Hilscher card)</u>			
DeviceNet or Profibus	EX5-HILUN-NA00	KWP-HILUN0-PRD	KWM-HILUN0-ATT
<u>Kepware - Special OPC Connectivity Tools</u>			
<u>OPC Bridging Software</u>			
LinkMaster OPC Bridging Software	LM3-LNKMS-NA00	KWP-LNKMS0-PRD	KWM-LNKMS0-ATT
<u>OPC Redundancy Server</u>			
RedundancyMaster Server	RM2-RDNMS-NA00	KWP-RDNMS0-PRD	KWM-RDNMS0-ATT
<u>OPC Client .NET Toolkit</u>			
ClientAce OPC .NET Toolkit	CA4-CLACE-NA00	KWP-CLACE0-PRD	KWM-CLACE0-ATT
<u>KepServerEX V6 - Other Drivers</u>			
ABB Totalflow	EX5-ABBTF-NA00	KWP-ABBTF0-PRD	KWM-ABBTF0-ATT
Allen-Bradley 1609 UPS	EX5-ABUPS-NA00	KWP-ABUPS0-PRD	KWM-ABUPS0-ATT
Allen-Bradley Bulletin 900	EX5-ABBL9-NA00	KWP-ABBLP0-PRD	KWM-ABBLP0-ATT
Alstom Redundant Ethernet Suite	EX5-ALSTM-NA00	KWP-ALSTM0-PRD	KWM-ALSTM0-ATT
Analog Devices	EX5-AD6BS-NA00	KWP-AD6BS0-PRD	KWM-AD6BS0-ATT
Aromat Suite	EX5-ARMCL-NA00	KWP-ARMCL0-PRD	KWM-ARMCL0-ATT
AutomationDirect / Koyo EBC	EX5-ADEBC-NA00	KWP-ADEBC0-PRD	KWM-ADEBC0-ATT
AutomationDirect / Koyo Suite	EX5-ATDRT-NA00	KWP-ATDRT0-PRD	KWM-ATDRT0-ATT
Beckhoff TwinCAT	EX5-BCFTC-NA00	KWP-BCFTC0-PRD	KWM-BCFTC0-ATT
Cutler Hammer Suite	EX5-CTHRM-NA00	KWP-CTHRM0-PRD	KWM-CTHRM0-ATT
Dataforth isoLynx	EX5-DFILX-NA00	KWP-DFILX0-PRD	KWM-DFILX0-ATT
Enron Modbus	EX5-ENRNM-NA00	KWP-ENRNM0-PRD	KWM-ENRNM0-ATT
Fanuc Focas Suite	EX5-GEFCS-NA00	KWP-GEFCS0-PRD	KWM-GEFCS0-ATT
Fisher ROC Suite	EX5-ROCP-NA00	KWP-ROCP0-PRD	KWM-ROCP0-ATT
Fuji Flex	EX5-FUJFX-NA00	KWP-FUJFX0-PRD	KWM-FUJFX0-ATT
Hilscher Universal	EX5-HILUN-NA00	KWP-HILUN0-PRD	KWM-HILUN0-ATT
Honeywell Suite	EX5-HYSTE-NA00	KWP-HYSTE0-PRD	KWM-HYSTE0-ATT
Idec Serial	EX5-IDCCL-NA00	KWP-IDCCL0-PRD	KWM-IDCCL0-ATT
IEC 60870-5 Suite (1-10 Devices)		KWP-608701-PRD	KWM-608701-ATT
IEC 60870-5 Suite (11+ Devices)	EX5-60870-NA00	KWP-608700-PRD	KWM-608700-ATT
IEC 61850 MMS Client (1-10 Devices)		KWP-618501-PRD	KWM-618501-ATT
IEC 61850 MMS Client (11+ Devices)	EX5-61850-NA00	KWP-618500-PRD	KWM-618500-ATT
Intelligent Actuator (IA) Super SEL	EX5-IASEL-NA00	KWP-IASEL0-PRD	KWM-IASEL0-ATT
IOtech PointScan 100	EX5-IOTPS-NA00	KWP-IOTPS0-PRD	KWM-IOTPS0-ATT
Krauss Maffei MC4 Ethernet	EX5-KRMFE-NA00	KWP-KRMFE0-PRD	KWM-KRMFE0-ATT
Lufkin Modbus	EX5-LUFKN-NA00	KWP-LUFKN0-PRD	KWM-LUFKN0-ATT
Mettler Toledo	EX5-MTSRL-NA00	KWP-MTSRL0-PRD	KWM-MTSRL0-ATT
Micro-DCI	EX5-FPMDC-NA00	KWP-FPMDC0-PRD	KWM-FPMDC0-ATT
MTConnect	EX5-MTCON-NA00	KWP-MTCON0-PRD	KWM-MTCON0-ATT
Omni Flow Computer	EX5-OMNIF-NA00	KWP-OMNIF0-PRD	KWM-OMNIF0-ATT
Optimation OptiLogic	EX5-OPTLG-NA00	KWP-OPTLG0-PRD	KWM-OPTLG0-ATT
Opto 22 Ethernet	EX5-OPTOE-NA00	KWP-OPTOE0-PRD	KWM-OPTOE0-ATT
Partlow ASCII	EX5-PTLWA-NA00	KWP-PTLWA0-PRD	KWM-PTLWA0-ATT
Philips P8/PC20	EX5-PHLP-NA00	KWP-PHLP0-PRD	KWM-PHLP0-ATT
SattBus Suite	EX5-SATBS-NA00	KWP-SATBS0-PRD	KWM-SATBS0-ATT
SIXNET Suite	EX5-SIXET-NA00	KWP-SIXET0-PRD	KWM-SIXET0-ATT
SquareD	EX5-SQRDS-NA00	KWP-SQRDS0-PRD	KWM-SQRDS0-ATT
Telemecanique Uni-Telway	EX5-TLMUW-NA00	KWP-TLMUW0-PRD	KWM-TLMUW0-ATT
Thermo Westronics Suite	EX5-THWSV-NA00	KWP-THWSV0-PRD	KWM-THWSV0-ATT
Tiway Host Adapter	EX5-SIUTW-NA00	KWP-SIUTW0-PRD	KWM-SIUTW0-ATT
Torque Tool Ethernet	EX5-TORQT-NA00	KWP-TORQT0-PRD	KWM-TORQT0-ATT
Toshiba Suite	EX5-TSBEN-NA00	KWP-TSBEN0-PRD	KWM-TSBEN0-ATT
Toyopuc Suite	EX5-TYP3E-NA00	KWP-TYP3E0-PRD	KWM-TYP3E0-ATT
Triconex Ethernet	EX5-TRCXE-NA00	KWP-TRCXE-PRD	KWM-TRCXE-ATT
WAGO Ethernet	EX5-WAGOE-NA00	KWP-WAGOE0-PRD	KWM-WAGOE0-ATT
Weatherford 8500	EX5-WFORD-NA00	KWP-WFORD0-PRD	KWM-WFORD0-ATT
WITS Suite (Wellsite Info Trans Spec)	EX5-WITSS-NA00	KWP-WITSS0-PRD	KWM-WITSS0-ATT
Yaskawa Suite	EX5-YKWMP-NA00	KWP-YKWMP0-PRD	KWM-YKWMP0-ATT
Yokogawa Controller	EX5-YKGRN-NA00	KWP-YKGRN0-PRD	KWM-YKGRN0-ATT
Yokogawa Suite	EX5-YKWDE-NA00	KWP-YKWDE0-PRD	KWM-YKWDE0-ATT
Yokogawa YS100	EX5-YKCTL-NA00	KWP-YKCTL0-PRD	KWM-YKCTL0-ATT